


SNAP® Link Serial Wireless Adapters

QUICK START: PLEASE READ THIS FIRST

Power


1. Apply power to Unit 1 using either the wall plug or a PC.
2. Apply power to Unit 2.



Pairing

1. Press and hold the MODE button on the first unit for over 5 seconds; release when LED "A" turns red. It will now flash red.
2. Standing near the first unit, press and hold the MODE button on unit 2; release when LED "A" turns red. The units are now paired.
3. Once paired, LED "A" flashes green to indicate good signal quality.


A flashing amber color indicates successful pairing, but with a weak signal.



Connect units to existing devices

How to reset to factory defaults:

1. Unplug the device.
2. While holding down the MODE button, plug the device back into a power source and wait until all LEDs turn amber, about 6 seconds.
3. Release the MODE button. LED "A" turns off to indicate success.



How to drop out of pairing mode:


1. Hold down the MODE button next to LED "A" for 5 seconds on one of the paired units.
2. It will drop out of paired state and go back into "pairing mode", indicated by the flashing red LED "A." If you click once quickly on that same unit, it should "re-pair" to the unit it was previously paired with.

SNAP® Link Serial Wireless Adapters

QUICK START: PLEASE READ THIS FIRST

Power


1. Apply power to Unit 1 using either the wall plug or a PC.
2. Apply power to Unit 2.



Pairing

1. Press and hold the MODE button on the first unit for over 5 seconds; release when LED "A" turns red. It will now flash red.
2. Standing near the first unit, press and hold the MODE button on unit 2; release when LED "A" turns red. The units are now paired.
3. Once paired, LED "A" flashes green to indicate good signal quality.


A flashing amber color indicates successful pairing, but with a weak signal.



Connect units to existing devices

How to reset to factory defaults:

1. Unplug the device.
2. While holding down the MODE button, plug the device back into a power source and wait until all LEDs turn amber, about 6 seconds.
3. Release the MODE button. LED "A" turns off to indicate success.



How to drop out of pairing mode:


1. Hold down the MODE button next to LED "A" for 5 seconds on one of the paired units.
2. It will drop out of paired state and go back into "pairing mode", indicated by the flashing red LED "A." If you click once quickly on that same unit, it should "re-pair" to the unit it was previously paired with.

SNAP® Link Serial Wireless Adapters

QUICK START: PLEASE READ THIS FIRST

Everyone at Synapse Wireless appreciates your purchase. We're saving trees, reducing waste, and ensuring you have the most up-to-date versions by providing our documentation and software online.

- User documentation can be downloaded from:
<http://forums.synapse-wireless.com/index.php>
(includes instructions for changing 2-wire settings to 4-wire RS-485 as well as configuring a point-to-multipoint installation.)
- Download SNAP EasySet configuration software to access additional configuration options using a Windows, Macintosh, or Linux computer from:
<http://www.synapse-wireless.com/SNAPLink/EasySet>
- Some parameters may be changed without using EasySet software by using the 8-bit DIP switch inside the unit, which is discussed further in the user documentation.



To learn more, visit
synapse-wireless.com
or call 877-982-7888



synapse®

SNAP® Link Serial Wireless Adapters

QUICK START: PLEASE READ THIS FIRST

Everyone at Synapse Wireless appreciates your purchase. We're saving trees, reducing waste, and ensuring you have the most up-to-date versions by providing our documentation and software online.

- User documentation can be downloaded from:
<http://forums.synapse-wireless.com/index.php>
(includes instructions for changing 2-wire settings to 4-wire RS-485 as well as configuring a point-to-multipoint installation.)
- Download SNAP EasySet configuration software to access additional configuration options using a Windows, Macintosh, or Linux computer from:
<http://www.synapse-wireless.com/SNAPLink/EasySet>
- Some parameters may be changed without using EasySet software by using the 8-bit DIP switch inside the unit, which is discussed further in the user documentation.



To learn more, visit
synapse-wireless.com
or call 877-982-7888


synapse®